



Recommended Trailer Maintenance Schedule

		3 Months or 3,000 Miles	6 Months or 6,000 Miles	12 Months or 10,000 Miles
Brake System				
Brakes	Test for Functionality	Every Use		
Brake Adjustment	Adjust to Proper Operating Clearance	•		
Brake Magnets	Inspect for Wear and Current Draw			•
Brake Linings	Inspect for Wear or Contamination			•
Brake Controller	Check Settings and Proper Operation	Every Use		
Brake Cylinders	Check for Leaks, Sticking			•
Brake Lines	Inspect for Cracks, Leaks or Kinks			•
Hubs / Drums	Inspect for Abnormal Wear or Scoring			•
Wheel Bearings & Cups	Inspect for Corrosion or Wear – Clean and Repack			•
Seals	Inspect for Leakage – Replace if Removed			•

Electrical System				
Battery	Test Cells With Hydrometer			•
Trailer Lights	Check That All Are Working	Every Use		
Trailer Brake Wiring	Inspect for Bare Spots and Fraying			•
Breakaway System	Check Battery Charge and Switch Operation	Every Use		

Running Gear				
Springs	Inspect for Wear and Loss of Arch		•	
Suspension Parts	Inspect for Bending, Loose Fasteners and Wear		•	
U-Bolts	Check for Wear and Confirm Tightness		•	

Tires and Wheels				
Tire Pressure	Inflate to Manufacturer Specifications	Every Use		
Tire Condition	Inspect for Cuts, Wear or Bulging	•		
Tire Replacement	Every 6 Years Regardless of Mileage			
Wheels	Tighten to Specified Torque	•		
Wheel Nuts and Bolts	Inspect for Cracks, Dents or Distortion	•		

Additional				
Couplers and Jacks	Inspect for Wear – Replace & Grease as Needed			•
Safety Chains	Check for Wear and Confirm Properly Fastened	Every Use		
Trailer Registrations	Make Sure It's Current	Every Use		